


MAXHUB Wireless Lavalier Microphone

Model: LM50



Quick Start Guide

V1.2

MAXHUB

Table of Contents

I. Package Contents 02

II. Product Introduction 02

III. Connection..... 04

IV. Simple Troubleshooting 04

Safety Instructions

Before operating this product, read and follow the instructions carefully to avoid dangerous or illegal operations.

1. Operating Environment

- Do not use the device in damp or humid locations to avoid internal circuit damage.
- Avoid hot environments or areas with direct sunlight.
- Optimal temperature range for use: 0-40°C, humidity range: 10%-90% RH.

2. Child Safety

The device and its parts may include small components. Keep them out of reach of children to prevent accidents.

3. Battery

- Do not let children touch the battery.
- Avoid exposing the battery to fire to prevent fire hazards.
- Use the correct poles when connecting the battery to avoid short circuits.

4. Water Protection

This device is not waterproof. Keep the equipment dry.

5. Maintenance

- All maintenance should be carried out by qualified personnel. If the device malfunctions, do not disassemble it yourself.
- Avoid inserting objects into any of the ports to prevent damage.
- Do not drop or subject it to strong impacts or vibrations to avoid product damage.

Special Statements

- Intellectual Property Rights: The hardware design and software of this product are protected by copyright law. Unauthorized copying of the manual or any part of the product will subject violators to legal consequences.
- This manual is for reference only. The final actual functions are subject to the functions of the product ordered and received by the customer.
- The images are for reference only. Please refer to the actual product. Our company reserves the right to improve and change the product's appearance and design without prior notice.

I. Package Contents

Please check if the following items are included in the package:


1. Wireless microphones × 2
2. Charging case × 1
3. Microphone Headset × 1
4. Windproof muffs × 2
5. Storage bag × 1
6. USB Type-C charging cable × 1
7. Quick Start Guide × 1

Note:


For detailed information on the device model and standard codes, please refer to the label.

II. Product Introduction

Before using the device, please familiarize yourself with its buttons and ports.



Main View



No.	Item	Description
1	Microphone display screen	Displays the working status of the microphone.
2	USB Type-C port	Supports power supply and upgrade.
3	Microphone three-in-one button	Used for power on/off, pairing, mute/unmute.
4	Volume "+" and "-" buttons	Adjust the microphone volume.
5	Audio input port	3.5mm microphone audio input.
6	Pogo pin port	For charging the microphone when paired with the charging compartment.
7	Power indicator for the charging case	Displays the current power level and charging/discharge status of the charging case.

III. Connection

1. Prerequisite for use:

This product needs to be used in conjunction with **MAXHUB** capture host or other portable external receivers.

2. Steps for use:

- i. Take out the microphone to power it on. It will automatically enter the pairing mode and the screen will show "Connecting" ;
- ii. Align the infrared pairing window of the microphone with the amplification equipment within a distance of 5 meters and up to 10 meters. It is recommended to stay within a horizontal angle of $\pm 45^\circ$;
- iii. Then the microphone can automatically complete the pairing, and it will be displayed on the screen.

3. Instruction:

This product is equipped with wireless pairing function. When it detects a speaker with wireless pairing function that is within 1 meter, the microphone will automatically pair. If pairing fails, double-click the three-in-one button to try pairing again.



NOTE

- 1) For better sound quality, keep the microphone towards your mouth within 15 cm.
- 2) Avoid placing the charging case near metal devices to prevent short circuit damage.
- 3) If the microphone cannot be charged or does not work after being charged, it is recommended to check if the charging cable or charging adapter is functional.
- 4) Try charging again after the microphone and charging compartment charging contacts.
- 5) If it is not convenient to lavalier or handheld use, you can pick up the mark through the headset, neck accessories to support the use of headset or neck.
- 6) When using outdoors, it is recommended to use the windproof muffs.

IV. Simple Troubleshooting

If the microphone does not work properly after powering on, please follow these steps to troubleshoot:

1. Check if it is muted.
2. Try increasing the microphone volume.
3. Re-pair the microphone with the device.
4. Check if it is connected to the wrong device.

