


Bracket Installation Guide

Model: TCP30WM




Quick Start Guide


V1.1

MAXHUB

Before wall mounting, please make sure that the accessories and screws below are included in the package:



Wall-mounted bracket ×1



Wall-mounted panel ×1



d×4

Wall anchor



e×4

KA3×30 Self-tapping
screw




f×4


M2.5×10 Screw

Step 1:

Use a 6 mm diameter drill bit to drill two holes 55 mm apart at appropriate positions on the solid wall, then insert 2 pieces of wall anchors d.


**Step 2:**

Use 2 pieces of KA3×30 self-tapping screws e to secure the wall-mounted panel to the wall with a screwdriver.




Step 3:

Loosen the 2 screws on the back of TCP30T Touch Console, and secure the wall-mounted bracket to the back of the touch console by tightening 2 pieces of M2.5×10 screws **f**.



Step 4:

Attach the console to the 2 keyhole slots on the wall-mounted panel and check that it is secure.



MAXHUB

